

On Demand Brings the Video Store to You

Access hundreds of shows and movies – anytime. You can reach **On Demand** from the **Quick Menu** or **Main Menu**, or from the **Flip Bar**, if available.



With **On Demand**² you can rent movies or programs from the On Demand library and watch shows at your convenience, as many times as you want within the rental period. You can even pause, fast-forward and rewind. Enjoy shows, movies, music videos and more on your schedule.

Pay Per View (PPV) Made Easy

Ordering **PPV**² movies and events is easy with i-Guide. From the **Quick Menu** or **Main Menu**, select the PPV option to see a list of available programs. Use your remote to get detailed information, watch a preview, and place an order.



Enhance Your Digital Cable Experience

With i-Guide, you'll find it easy to find and discover the programs you love. With enhanced search capabilities and new DVR recording management tools, you can enjoy your favorites shows anytime.

Remote Control Features


Basic Navigation

- It's easy to get started. Press the **GUIDE** button on your remote to access the Listings By Time grid
- **Yellow** is always the highlight color. As you navigate listings, the highlight appears on screen to indicate the current selection
- Press the ◀ ▶ or ▲ ▼ arrows to move the highlight
- Press **OK/Select** to tune to a show or to access program information
- Press the **EXIT** button to return to watching TV



Digital Video Recording (DVR)

Pause live television. Rewind and replay programs. Record your favorites all season long. With **DVR**², you're in control from the comfort of your own home. And with dual-tuner DVR, you can watch one program while recording another.



Control Live TV

Any time you tune to a channel, the DVR starts a temporary recording. So you can **PAUSE** if the phone rings, **REWIND** the scene you missed, and **FAST-FORWARD** to skip what you don't want to watch.

DVR Puts You In Control

Build Your Own Personal Video Library

It's easy to record with i-Guide. Press **REC** on your remote anytime while watching TV for easy one-touch recording. Press **REC** from the **Program Info** screen to set up a one time or series recording, or even set up an auto-recording from any **Search** results screen.

Your Recordings Your Way

i-Guide helps you easily manage your recordings. Access the **DVR Menu** from **DVR** on the **Quick Menu** or **Main Menu**. From here select **My Recordings** to view your list.



Series recordings are automatically grouped into **Folders** so you can quickly scroll through your list. Use the ▲ ▼ arrows to select a series and press **OK/Select**. Scroll through the list to find the episode you want to see.



DVR Cleanup lets you delete multiple shows at once, and **DVR History** keeps track of shows that were deleted. i-Guide makes it simple to organize your shows so you can enjoy watching on your schedule.



inside i-Guide™

quick reference guide



Call: 800-952-1001
Click: MetroCast.com

¹ Menu selections vary depending on the services your cable provider offers.

² PPV, On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR.

Copyright ©2010 Rovi Corporation. Rovi and i-Guide are trademarks of Rovi Corporation and/or its subsidiaries.

Quick Menu: Quick & Easy

The **Quick Menu** offers shortcuts to key i-Guide features. Just press MENU on your remote anytime while using the guide or watching TV, and you'll have easy access to your **DVR**, **On Demand** and **HD** programming, **Search**, and **Parental Controls**.



Press the ◀ ▶ arrows on your remote to highlight an option, press OK/SELECT and you're on your way.

Mini Guide

Mini Guide lets you watch television and view listings without having to leave your program. To access, press OK/Select then use the ◀ ▶ arrows to browse time and ▲ ▼ arrows to browse channels.




Smart Channel Surfing

The **Flip Bar** provides program information as you change channels, plus, you can even tune easily to the associated HD channel or On Demand. Press OK to select, or INFO for program details.

Parental Controls


Parental Controls allow you to restrict viewing and purchases of TV programs based on your preferences. Set a personalized 4-digit PIN to place locks on selected movie & TV ratings, TV content ratings, channels, and titles. You can also hide adult titles from being displayed on screen.



Select from the Quick Menu to set up Parental Controls and PINs.

All Access With Main Menu

From the **Main Menu**, you can access all i-Guide features. Press MENU twice, then select from the options, including **Listings By Time**, **Search**, **DVR**, **Local Weather**, **Setup** and more.



Instant Program Info

i-Guide provides **Instant Information** while you view program listings, including program title, start/end time, and a brief description including ratings. Helpful indicators identify settings, such as **Reminders**, **Recordings**, **Locks** and **Favorites**.



Enhanced Searching

i-Guide offers expanded search capabilities so you can find your favorite shows faster as well as discover new ones. Search by **Category** or by **Title**, **Keyword** or **Actor/Director**. Access Search from the on the **Quick Menu** or from the **Main Menu**.



Listings By Time

Press GUIDE to access **Listings By Time**. Channel numbers and network call letters appear on the left with times along the top. Use ◀ ▶ ▲ ▼ arrows to navigate the lineup and to go forward in time.



Color coding makes it easy:

Blue – Regular programs
Purple – Movies

Green – Sports
Light Blue – Kids' programs

Action Icons

From the Listings By Time grid, press INFO to learn more about a program. Use the **Action Icons** at the bottom to set **Recordings**, **Reminders**, **Parental Controls**, and more.



Use the arrow ◀ ▶ buttons to highlight an icon.



When searching by **Keyword**, **Title**, or **Actor/Director**, use the keyboard to spell out your request. i-Guide will search for shows. You can select **Save Search** or set an **Auto-Recording** right from any **Search** results screen.



Go Ahead, Play Favorites

Create up to five **Favorites** lists – one for everyone in the family. Select from the **Quick Menu**, or My Favorite Channels from the **Main Menu**.

quick reference